
4	3	2		1
INSTALLATION INSTRUCTIONS *SPECIFICATIONS VARY PER BUILD				
1 REFER TO HARD COPY INSTRU	ICTIONS INCLUDED WITH YOUR UNIT			
OR				D
2 SCAN QR CODES ON YOUR UNIT				
(1) ENCLOSURE INSTALLATION INSTRUCTIONS				
2 LIFTING	STRUCTIONS Y FER BUILD IFT POINT IFT POINT D DDDES ON YOUR UNIT IFT POINT ROOF D DDDES ON YOUR UNIT IFT POINT ROOF D ISTALLATION INSTRUCTIONS ISTALLATION INSTRUCTIONS D D ISTALLATION INSTRUCTIONS ISTALLATION INSTRUCTIONS D C ISTALLATION ISTALLATION INSTRUCTIONS DOORS DOOR HOOK & LATCH C ISTALLATION ISTALLATION - COLUMN COUPLER ISTALLATION - COLUMN COUPLER D D INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) SOU TYP INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) B INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) SOU TYP INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) B INTERNAL SOU TYP INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) B INTERNAL SOU TYP INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION)			
3 POSITIONING	ΤΟΡ ΡΑ			
(4) LEVELLING				
(5) LEVELLING DOORS DOOR HOOK & LATCH				
(6) SECURING TO FOUNDATION				
(7) THERMOSTAT & ELECTRICAL	DOOR			
(8) UPPER MODULE INSTALLATION				
(9) UPPER MODULE INSTALLATION				
(10) UPPER MODULE INSTALLATION	10 UPPER MODULE INSTALLATION - COLUMN COUPLER			
(1) UPPER MODULE INSTALLATION	- COUPLING BRACKET			
	COLU	MN /		
ENCLOSURE INSTALLATION				
EX CE				
	Dides ON YOUR UNIT INSTALLATION INSTRUCTIONS INSTALLATION INSTRUCTIONS INSTALLATION INSTRUCTIONS S TOP PANEL INSTALLATION INSTRUCTIONS DOOR HOOK & LATCH C DOOR HOOK & LATCH ULE INSTALLATION DOOR HOOK & LATCH INSTALLATION DOOR HOOK & LATCH ULE INSTALLATION DOOR HOOK & LATCH INSTALLATION CULUMIN ULE INSTALLATION CULUMIN COUPLER ULE INSTALLATION COUMIN COUPLER ULE INSTALLATION COUMIN COUPLER INSTALLATION COUPLER INSTALLATION PHONE OR DEVICE <			
	AIR GAP INTERNAL COLUMN PAD (FOR MOUNTING TO FOUNDATION) B ADDITIONAL DOCUMENTS INCLUDED WITH YOUR BUILD: B			
SCAN WITH YOUR DEVICE				
* ROOF INSTALLATION & REMOVAL				
* LOOK FOR STICKERS LOC		RPS ENCLOSURES		
SCAN CODE WITH YOOR P	HONE OR DEVICE.			
GENERAL NOTES: 1. THIS DOCUMENT IS FOR INSTALLATION & MAINTENANCE REFERENCE ONLY 2. ENCLOSURE SHALL BE INSTALLED BY CONTRACTOR. 3. THE ENCLOSURE SHALL BE INSTALLED BY CONTRACTOR.		THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF	Installation instructions Installation instructions	
		WITHOUT THE WRITTEN PERMISSION OF RPS INDUSTRIES IS		
	E FOR OR DURING INSTALLATION.			WWW.RPSUSA.COM
6. SPECIFICATIONS VARY PER BUILD	3	DO NOT SCALE DRAWINGS FROM THIS SHEET	DATE: 5/19/2022 DRAWN: AJ REV:	SHEET 1 OF 11
4	3	2		I

D

С

В

А





*LIFT USING ALL PREINSTALLED LIFT POINTS *SPECIFICATIONS VARY PER BUILD

4

D

С

В

А

1.


2

GENERAL NOTES:

1 SQUARE YOUR BUILDING ON IT'S FOUNDATION PRIOR TO LEVELLING (SHEET 4)


2 CHECK YOUR BUILDING IS SQUARE BY MEASURING INTERNAL CROSS SECTIONS.

3





3





THE ENCLOSURE SHALL BE INSTALLED WITH A BOOM TRUCK OR EQUIVALENT. 3 4. THE CONTRACTOR SHALL NOT DISASSEMBLE PUMP ENCLOSURE FOR OR DURING INSTALLATION. 5. CONCRETE SLAB, ELECTRICAL CONNECTIONS AND ANCHOR BOLTS NOT PROVIDED BY RPS INDUSTRIES. 6. SPECIFICATIONS VARY PER BUILD

ENCLOSURE SHALL BE INSTALLED BY CONTRACTOR.

4

THIS DOCUMENT IS FOR INSTALLATION & MAINTENANCE REFERENCE ONLY





SPECIFICATIONS VARY PER BUILD

4



3

DRAWING NO.

2

DATE:

REV:

1

SHEET 5 OF 11

